

Medicine cabinet M-PT PharmaTower

The M-PT PharmaTower medicine cabinet is primarily intended for the systematic storage and distribution of medicines in prescription areas of pharmacies and in hospital treatment rooms. The product is based on a system of drawers that can be opened in full length. The drawers have a soft-close function. The number and height of drawers can be customised. The drawer bottoms are transparent and the drawers include flexible dividers.



The body of the medicine cabinet is made of quality melamine. The front finishing can be chosen from among Merianto's standard finishings, or it can be customised according to client's wishes. The load capacity of the drawers is 25 kg.



The dimensions of the M-PT medicine cabinet:

- Width: 420mm (plus the width of end panel 20mm)
- Height: 2100mm
- Depth:
 - S6 - 670mm (depth of drawer 600mm)
 - S9 - 930mm (depth of drawer 750mm)
 - S12 - 1205mm (depth of drawer 1000mm)
 - S13 - 1305mm (depth of drawer 1100mm)



EGGER W1100 white EGGER U702 gashmere gray EGGER U630 lime green EGGER U222 crema beige EGGER H1277 light acacia



The standard solution of the M-PT medicine cabinet includes:

- 18mm melamine body and front panels
- The selection of materials also includes an antibacterial surface finish.
- Fully opening drawers with soft-close mechanism
- Drawer bottoms made with safety glass or steel net
- Flexible dividers in drawers
- Special handles with alphabet
- Strong metal feet frame with adjustable feet

The product datasheet shows the dimensions and finishes of standard Merianto medical furniture solutions. Based on this, customised solutions with suitable finishing can be produced.